



Figure 13c: Valley Product Application

Order of applying Certi-label® shakes or shingles at valley:

1. Stop course line here

2. Place pre-cut valley piece so that cut-angle is positioned on the valley guide chalk line with tip on the course line.

3. Select product of the required width to complete the course of Certi-label® shakes or shingles.