



**Pressure-Impregnated Treated Products**

Certi-label® products can also be treated. Products are available either fire-retardant-treated OR preservative-treated. Special care must be taken to follow the treatment company’s recommended installation instructions.



**Certi-Guard® Fire-Retardant Treated Western Cedar Shingles and Shakes**

Number 1 Grades of Certigrade® shingles, and Premium and Number 1 Grades of Certi-Split shakes® and Certi-Sawn® shakes are available pressure-impregnated treated with fire retardants. Contact the treatment company for treatment warranty information, accessory product requirements (including recommended fastener types) and application details for treated Western Cedar material. Local code jurisdictions may have additional information regarding applications in specific areas.



**Certi-Last® CCA Preservative-Treated Western Cedar Shingles and Shakes**

Number 1 Grades of Certigrade® shingles, and Premium and Number 1 Grades of Certi-Split® shakes and Certi-Sawn® shakes are available preservative-treated by pressure impregnation process. This product is ideal in areas of high humidity. Specify the Certi-Last® treating label for this extra protection. Contact the treatment company for treatment warranty information, accessory product requirements (including recommended fastener types) and application details for treated Western Cedar material.

**Note:**

- Once Western Cedar shingles and shakes are pressure-impregnated treated you must contact the treatment company to determine if a finish, such as paint or stain or cleaning solution/agent, is allowable.
- Confirm product labels required for warranty registration BEFORE purchasing product. Ensure details are listed on purchase order.

**Certi-label® Sidewall Application Tips**

Certi-label® Western Cedar shingle and shake size, exposure, width of joints, width of product, kiln versus air-drying process, moisture content and the local environment will all affect the expansion/contraction of Certi-label® Western Cedar sidewall products. These factors should always be taken into consideration when

determining the installation details and adequate spacing needed for your specific project. Consult with your installer and refer to this manual for more lateral spacing details.

It is suggested that shingles from several job-specific boxes are blended during the installation process.