

Certi-label® Shingles

There are two acceptable methods for application of spaced sheathing: One is to space 1 x 4 boards to coincide with the weather exposure of the shingles (Table 2, Page 25) (**Figure 5**). Thus, if the shingles are to be laid at 5 1/2" to the weather, the sheathing boards would also be spaced at 5 1/2" on center. In this method of application each shingle is nailed to the center of the 1 x 4 board. With 7 1/2" weather exposures, the center of the sheathing board shall equal the distance of the weather exposure.


Alternatively, although not commonly used, a permeable underlayment (i.e. breathable), such as roofing felt, may be applied over either solid or spaced sheathing.



NOTE:

- The only solid sheathing product tested for use with Certi-label® shakes and shingles is plywood. Check with your local building code official for plywood thickness/ dimensions.

Figure 5: Certi-label® Shingle Application



Certi-label® Shingle Application

Regardless of style, the following basic application details (**Figure 5**) must be observed.

- Shingles must be doubled or tripled at all eaves.
- Butts of first course shingles should project 1 1/2" beyond the fascia and approximately 1" over the gable or rake end.
- Spacing between adjacent shingles (joints) should be a minimum of 1/4" and a maximum of 3/8".
- Certi-label® shingles shall be laid with a side lap not less than 1 1/2" between joints in adjacent courses and not more than 10% shall be in direct alignment in alternate courses. Check with your local building code official in your area.
- In lesser grade shingles (**Figure 5a**) containing both flat and vertical grain, joints should not be aligned with centerline of heart.
- Flat grain shingles wider than 8" should be split in two before nailing. Knots and similar defects should be treated as the edge of the shingle and the joint in the course above placed 1 1/2" from the edge of the defect.

Figure 5a: Course Alignment

